

<b>GP AIR (cm)</b>	<b>S</b>	<b>M</b>	<b>L</b>	<b>L-L</b>	<b>XL</b>	<b>XL-L</b>
<b>Height</b>	160-180	165-185	170-190	170-190	175-195	175-195
<b>Chest line with equipment</b>	75-85	80-90	85-95	90-100	90-105	95-115
<b>Waist line with equipment</b>	65-80	70-85	75-90	80-95	80-100	85-110
<b>Hip line with equipment</b>	70-90	80-95	85-100	90-105	90-110	95-115
<b>Back length</b>	45-60	50-65	55-70	55-70	60-75	60-75
<b>Cartridge</b>	60 CC	60 CC	60 CC	60CC	60 CC	60 CC

*This size chart is for information only. The vest should have a close-fitting for the aerodynamics and it must go down 10 cm under the iliac crest (hip bone). Caution, you must not wear Helite airbag if you weigh less than 35 kg.*